



User Guide
AC801 Intelligent Machine Controller

19011384 A00

Thank you for purchasing the AC801 intelligent machine controller developed and manufactured independently by Inovance.

Safety Instructions

- Safety Precautions
1. Before installing, using, and maintaining this equipment, read the safety information and precautions thoroughly, and comply with them during operations.

Safety Levels and Definitions

- WARNING: The "WARNING" sign indicates that failure to comply with the notice may result in severe personal injuries or even death.

During control system design

- WARNING: Provide a safety circuit outside the PLC so that the control system can still work safely once external power failure or PLC fault occurs.

Installation

- WARNING: Installation must be carried out by the specialists who have received the necessary electrical training and understood enough electrical knowledge.

- CAUTION: Prevent metal filings and wire ends from dropping into ventilation holes of the PLC during installation.

Wiring
WARNING: Wiring must be carried out by personnel who have received the necessary electrical training and understood enough electrical knowledge.

Operation and Maintenance
WARNING: Maintenance & inspection must be carried out by personnel who have the necessary electrical training and experience.

Disposal
CAUTION: Treat scrapped module as industrial waste. Dispose the battery according to local laws and regulations.

Product Information

Model Number
AC801-0221-U0R0
Nameplate
MODEL AC801-0221-U0R0
CPU Intel3855U 1.6GHz

Nameplate
MODEL AC801-0221-U0R0
CPU Intel3855U 1.6GHz
Memory 4GB DDR 4
Hard drive M.2 64G SATA

Table with 4 columns: Product Type, Description, Model, Serial No.

General Specifications

Table with 2 columns: Item, AC802-0221-U0R0

Table with 2 columns: Item, AC802-0221-U0R0




Figure 2 Diagram of controller interfaces

Table with 4 columns: No., Name, Function, Description

Table with 2 columns: Button, Function

I/O communication interface




Table with 7 columns: Description, Function, Signal Name, No., No., Signal Name, Function, Description

Table with 4 columns: No., Name, Function, Description

Table with 5 columns: Terminal, No., Name, Type, Function

Table with 2 columns: Grounding terminal, Description

Table with 2 columns: DVI-D interface, Description

4 LAN ports: LAN A, LAN B, LAN C and LAN D (top to bottom).

Table with 5 columns: Indicator, Function, Color, State, Meaning

Description:

Table with 3 columns: Port, Function, Function

The controller provides 4 USB interfaces, all of which support plug-and-play and hot plugging, and can connect up to 127 external devices.

Table with 4 columns: Pin, Signal Name, Function

No.	Name	Function	Description	
13	Power button	The controller power button is located under the front panel of the controller. See the following for the details:		
		No.	Operation	Result
		1	Power-on	The controller is turned on
		2	Pressing the button after power-on	No operation
		3	Long pressing the button after power-on	The controller is shut down
4	Pressing the button after the controller is shut down but power is still on	The controller is turned on		

■ Spare parts and options

No.	Name	Illustration	Description	Ordering code
1	RTC button battery CR2032		3 V, 230 mAh	09050002
2	Side earhook bracket		The booksize controller is installed through an earhook. A side earhook is available as an option for special scenarios.	20181483
3	UPS		An external UPS is required for power failure retention. The controller supports Weidmüller's CP DC BUFFER 24 V 20 A.	72030012 (Part no.: 24 VDC BUFFER 5AS)

Mechanical Design Reference

■ Dimensions




Figure 3 Controller dimensions (rear earhook) (in mm)




Figure 4 Controller dimensions (side earhook) (in mm)

Connection and Use

■ EtherCAT bus connection

- 1) EtherCAT specifications
- EtherCAT bus specifications

Item	Specifications
Communication protocol	EtherCAT protocol
Service supported	CoE (PDO, SDO)
Min. sync period of 6-axis cam	1250 us (typical)
Max. synchronous jitter	±40 us
Synchronization mode	The servo adopts a DC-distributed clock and the IO module adopts input/output synchronization
Physical layer	100BASE-TX
Baud rate	100 Mbit/s (100Base-TX)
Duplex mode	Full duplex

Item	Specifications
Topology	Linear
Transmission medium	Network cables, see the Wiring section
Transmission distance	Less than 100 m between two nodes
Number of slaves	Single EtherCAT port, supporting 128 slaves (axes up to 48)
EtherCAT frame length	44–1498 bytes
Process data	Max. 1486 bytes per Ethernet frame

2) Wiring

The controller provides a LANC port and a LAND port for EtherCAT bus communication. The cable must meet the following requirements:

ECT cable:




Figure 5 Requirements on the EtherCAT cable

- Signal pins

Pin	Signal (Ethernet 1000 Mbps)	Signal Direction	Signal Description
1	TD+	Output	Data transmission+
2	TD-	Output	Data transmission-
3	RD+	Input	Data reception+
4	--(DC+)	--(bidirectional)	Not used (data C+)
5	--(DC-)	--(bidirectional)	Not used (data C-)
6	RD-	Input	Data reception-
7	--(DD+)	--(bidirectional)	Not used (data D+)
8	--(DD-)	--(bidirectional)	Not used (data D-)

Note: The definition of pins 4, 5, 7, and 8 under 1000 Mbps differs from that under 100 Mbps. Pay attention to the information in parentheses.

- Length requirements:

According to FastEthernet technology, when an EtherCAT bus is used, the length of the cable between the devices must not exceed 100 meters. Exceeding this length will attenuate the signal and affect communication.

- Technical requirements:

100% continuity test, no short circuit, open circuit, misalignment and poor contact. It is recommended to use the following cables:

Item	Specifications
Cable type	Flexible crossover cable, S-FTP, Cat 5e
Complied standards:	EIA/TIA568A, EN50173, ISO/IEC11801 EIA/TI Abulletin TSB, EIA/TIA SB40-A&TSB36
Conductor cross section	AWG26
Conductor type	Twisted pair
Pair	4

■ RS485 bus connection

1) Networking diagram

The RS485 bus topology is shown below. Using shielded twisted cables to connect CAN bus is recommended. Two 120 Ω termination resistors are attached to both ends of the bus to prevent signal reflection. Reliable single-point grounding is often used for shielded layers.




Figure 6 Diagram of RS485 communication connection

2) Terminal wiring

The controller provides three terminals (485+, 485- and GND) Series for RS485 communication. Ensure that the RS485 bus contains three cables, and the terminals are connected correctly.




Figure 7 Terminal connection

■ Ethernet Connection for Monitoring

1) Networking diagram

With the Ethernet port, controller can be connected point-to-point with devices such as a computer and HMI through an Ethernet cable




Figure 8 Connection between controller and PC

The CPU module can also be connected to a hub or switch, which is further connected

with other network devices, through an Ethernet cable to achieve multi-point connection.




Figure 9 Connection between controller and other devices through a switch

2) Wiring

To improve power communication reliability, the Ethernet cable must be Cat5 shielded twisted pair with an iron shelled connector.

■ Wiring of UPS and status I/Os

To enable power failure retention, a 24 VDC BUFFER 5AS UPS is required. The recommended wiring method for UPS and other I/O control signals is shown in the figure below:




Figure 10 UPS connection

- ◆ The UPS requires an external 24 V power supply. It is recommended to use a switched-mode power supply with a load capacity of 10 A and above;
- ◆ If the controller is powered on when the UPS Ready indicator is not completely off, it may not be started. In this case, you need to start the controller manually;
- ◆ When the UPS is connected, ensure that UPS Fail output is connected with the controller after power-on, otherwise the controller will be shut down.

Programming tool download

Inovance provides InoProShop as the user programming tool for AC800 series intelligent machine controllers. It is free and you can obtain a DVD copy from our distributors or download it from our website www.inovance.com, where you can also download documents about AC800 series PLC products and their applications.

Due to the continuous improvement of products and information by the company, you are recommended to timely update the software and related documents.

■ Programming Environment and Software Installation

Environmental requirements

Hardware: A PC running Windows 7 or 10 (x64 is recommended), with 4 GB RAM and a hard disk or SSD with more than 5 GB free space. To ensure performance, the CPU frequency should be above 2 GHz.


The PC can be connected with the controller through a LAN cable. It is recommended to use a router between the PC and controller. That allows for longer distance and faster communication speed between them, and you can sit in your office and program the controller running in the workshop, for example. Therefore, a free LAN network port in the local network and a network cable are required.

Installation

1) Grounding of the housing

A ground point is set on the power terminal of the controller and the rear earhook. Choose one of the grounding points as needed, and ground the controller with a grounding wire that is as thick and short as possible (less than 30 cm). It is recommended to use the grounding point on the rear earhook as possible.

A wing nut is used for grounding, with a tightening torque of 0.55–0.8 N · m:



1-Wing nut; 2-grounding cable; 3-Grounding screw

Figure 11 Grounding diagram




NOTE

- ◆ Ensure that the wing nut is tightened to the required torque;
- ◆ For your safety, ensure that the grounding is correct and reliable.

2) Installation space

To facilitate ventilation and module replacement, keep enough space between the module and its surroundings.

Installation diagram



Rear earhook bracket installation

Side earhook bracket installation

Figure 12 Installation space for booksize controller


Direction	Min. dimension requirements (mm)
X	50
Y	100
Z	50

3) Installation methods


The booksize controller can be installed through a rear earhook (booksize) or a side earhook (wall-mounted) to be adapted to cabinets of different sizes. The controller must be tightened with four screws to a tightening torque of 1.2 N · m.

The controller is delivered with a rear earhook for booksize installation. The side earhook is optional for special occasions.

1) Rear earhook



2) Side earhook



NOTE

- ◆ Before installation, ensure that the controller is powered off;
- ◆ For the hole size, see "Mechanical Design Reference";
- ◆ To avoid damage to the terminal and controller, tighten all fasteners to the specified torque.

INOVANCE Warranty Agreement

The warranty period of the product is 18 months (subject to information indicated by the barcode on the product). During the warranty period, if the product fails or is damaged under the condition of normal use by following the instructions, Inovance will be responsible for free maintenance.

Within the warranty period, maintenance will be charged for the damages due to the following causes:

- 1) Improper use or uninstallation/repair/modification without prior permission
- 2) Fire, flood, abnormal voltage, other disasters, and secondary disasters
- 3) Hardware damage caused by dropping or transportation after procurement
- 4) Failure to operate the product by observing the User Guide provided by Inovance
- 5) Faults and damages caused by factors outside of the product (such as peripheral devices)

The maintenance fee is charged according to the latest Maintenance Price List of Inovance.

The Product Warranty Card is not re-issued. Keep the card and present it to the maintenance personnel when seeking maintenance.

If there is any problem during the service, contact us or our agent directly.

You are assumed to agree on terms and conditions of this warranty agreement by purchase of the product. This agreement shall be interpreted by Suzhou Inovance Technology Co., Ltd.